

Type EM-TRF-USV



FOR THE CONNECTION OF EASYLAB TO THE 230 V MAINS AND FOR UNINTERRUPTIBLE POWER SUPPLY

Expansion module for the direct connection of EASYLAB controllers
Type TCU3 and adapter modules Type TAM to the 230 V mains, including
uninterruptible power supply

- Double-stack terminal blocks for 230 V supply voltage connection
- Electric plug connection to the main PCB
- The expansion module is fitted into the casing with the EASYLAB base component
- Uninterruptible power supply for the connected modules
- Integral battery charging electronics with charge status indicator
- Power failure is signalled to the EASYLAB control panels
- Controller action in case of a power failure can be defined



Application

- Expansion module Type EM-TRF-USV for the EASYLAB system
- For the connection of EASYLAB base components (controller TCU3 or adapter module TAM) to the 230 V AC supply voltage (mains)
- Power supply for the base component and the connected modules
- Battery pack ensures uninterrupted power supply even in case of a mains power failure
- Control and/or alarm signalling even in case of a power failure
- Factory mounted or for retrofitting into the EASYLAB base component casing

Special characteristics

- Ready for installation, can be easily connected to the main PCB
- Double-stack terminal blocks for 230 V AC supply voltage connection
- Simple electrical connection of expansion module and EASYLAB main PCB using a connection plug
- Simple wiring of switch-operated fume cupboard lighting in combination with the EM-LIGHT expansion module
- Intelligent charge control with trickle charging, deep discharge protection, and reverse voltage protection
- Operating state indicator light
- Controlled response in case of a power failure can be defined (EASYLAB TCU3 with expansion module EM-TRF-USV)
- In case of a power failure: Optical signal on the control panel; configurable alarm

signalling

Parts and characteristics

- Mains transformer 230 V AC (primary), 24 V AC (secondary)
- Intelligent charge control with trickle charging, deep discharge protection, and reverse voltage protection
- Operating state indicator light
- PCB plug connector to connect the module to the EASYLAB main PCB

Useful additions

- EasyConnect: Configuration software for the commissioning and diagnosis of EASYLAB components

Construction features

- PCB dimensions and fixing points correspond to the EASYLAB main PCB and the casing
- Fixing with screws
- Double-stack terminal blocks for simply 230 V supply voltage connection

TECHNICAL INFORMATION

Function, Technical data, Specification text, Order code, Related products 

Product details 

Installation details 

TROX UK Ltd



Caxton Way,
Thetford, Norfolk, IP24 3SQ, UK
Tel: +44 (0) 1842 754545
Fax: +44 (0) 1842 763051

General Enquiries –
info@troxuk.co.uk
Sales & Customer Services –
sales@troxuk.co.uk
Accounts –
accounts@troxuk.co.uk

Online-Services

- [TROX Academy](#)

- [Your contact partner](#)

- [Our Office London](#)

- [Our Office Thetford](#)

Service-Hotlines

Sales:
+44 (0)1842 754545
[Contact](#)

Service:
+44 (0)1842 754545
[Contact](#)

Technical service
+44 (0)1842 754545
[Contact](#)

TROX SOCIAL MEDIA
